



Electrical Injuries

- Shocks and burns.
- •Low voltages can cause enough current to create problems.
- •Equipment today uses lower voltage than tube equipment but it can still cause burns.

Effects of Electric Current in the Human Body

Current	Reaction
Below 1 milliampere	Generally not perceptible
1 milliampere	Faint tingle
5 milliamperes	Slight shock felt; not painful but disturbing. Average individual can let go. Strong involuntary reactions can lead to other injuries.
6-25 milliamperes (women) 9-30 milliamperes (men)	Painful shock, loss of muscular control*; the freezing current or "can't let-go" range.
50-150 milliamperes	Extreme pain, respiratory arrest, severe muscular contractions. Death is possible.
1000-4300 milliamperes	Rhythmic pumping action of the heart ceases. Muscular contraction and nerve damage occur; death likely.
10,000 milliamperes	Cardiac arrest, severe burns; death probable

^{*} If the extensor muscles are excited by the shock, the person may be thrown away from the power source.

Source: W.B. Kouwenhoven, "Human Safety and Electric Shock," Electrical Safety Practices, Monograph, 112, Instrument Society of America, p 93. November 1968.



- Avoiding contact is the most effective way of practicing electrical safety
- Unplug equipment before working on it
- Keep one hand in your pocket
- Make sure equipment is grounded
- Use power from GFCI-protected circuits

Mitigating Electrical Hazards


- •If working on live equipment is required:
 - Remove jewelry
 - Avoid unintentional touching of circuitry
 - Never bypass safety interlocks
 - Discharge high-voltage points and components to ground
 - Capacitors can store charge after power is off
 - Storage batteries are dangerous when shorted

Responding to Electrical Injury

- •REMOVE POWER!
 - Have ON/OFF switches and circuit breakers clearly marked.
 - Install an emergency master power switch and make sure your family knows how to use it.
- Call for help.
- •Learn CPR and first aid.

Electrical Grounding and Circuit Protection

- Make sure your station wiring meets code
- Most ham equipment does not require special wiring or circuits
 - -Use 3-wire power cords
 - -Use circuit breakers, circuit breaker outlets, or Ground Fault Circuit Interrupter (GFCI) circuit breakers or outlets
 - -Use proper fuse or circuit breaker size
 - -Don't overload single outlets or circuits



- •RF burns from "hot spots" at high RF voltage
 - •Do not cause serious injury at ham power level
 - •Prevent by bonding (connecting) equipment together with heavy wire or strap braided strap not recommended at RF
 - •Prevent by keeping people away from antennas and radial or counterpoise wires
- Ground equipment for AC safety



- •Ground antennas and towers to local code
 - •Use 8-ft ground rod for each tower leg
 - •Bond rods to tower leg and the other rods
- •Ground connections should be as short as possible
- •Use lightning arrestors on a single ground plate where cables enter the house
- Unplug and disconnect equipment (including telephones and computers) and feed lines if lightning is expected




- Electromagnetic radiation (EMR) is not the same
 as radioactivity much lower energy
- RF energy heats body tissues
 - -Heating depends on the RF intensity and frequency.
 - -If precautions are taken, RF exposure is minimal and not dangerous.



- Power Density
 - Watts per square centimeter (w/cm²)
- Higher power density means higher RF exposure
- RF absorption varies with frequency because of body part size
- Safe exposure levels have been established by the FCC

Maximum Permissible Exposure (MPE)





- Controlled Environment.
 - -You know where people are standing in relation to your antenna and you can do something about it.
 - -Higher power density is allowed because you can make adjustments if needed.



- Uncontrolled Environment.
 - -You have no control of people near your antenna.
 - -Lower power density is allowed because you cannot control or adjust the exposure of people.

Duty Cycle and Duty Factor

- •Duty cycle is the percentage of time that a transmitter is on during the evaluation period, from 0 to 100%
 - •Duty cycle = $100 \times (time on / total time)$
- •Duty factor is the same as duty cycle, but given as a number from 0 to 1.0
- •Higher duty cycle or factor means higher average power density and exposure

Mode Duty Cycle

•Accounts for the different characteristics of the transmitted signal's waveform

Operating Duty Factor of Mi	oues common
Mode	Duty Cycle
Conversational SSB	20%
Conversational SSB	40%
SSB AFSK	100%
SSB SSTV	100%
Voice AM, 50% modulation	50%
Voice AM, 100% modulation	25%
Voice AM, no modulation	100%
Voice FM	100%
Digital FM	100%
ATV, video portion, image	60%
ATV, video portion, black screen	80%
Conversational CW	40%
Carrier	100%



- •All fixed stations must perform an exposure evaluation.
 - Use online calculator (easiest)
 - Model exposure with software (difficult)
 - Measure RF power density (most difficult)



- An RF Exposure evaluation is required when a station is built or altered. The previous exclusion for some power levels and frequencies presented in your manuals has been recinded by the FCC!
- Re-evaluate exposure when station equipment or operating frequencies change.



- Relocate or reorient antennas
- •Raise the antenna
- Reduce antenna gain
- Reduce RF power output
- Change to a lower duty cycle mode

Mobile Safety

- Mobile Installations
 - Secure all equipment
 - Place equipment where you can operate it safely while driving
 - Know local rules for use of communications equipment while driving
 - May need hands-free microphone




- Keep antennas well away from power lines
- Check for power lines before installing antennas in trees
- Provide a minimum of 10 feet of clearance if antenna falls
- Never attach antennas or guy lines to utility poles or structures

Tower Work


- Basic tower safety
 - -Proper clothing, hard hat and eye protection
 - -Use a proper climbing harness, not a lineman's belt or rock-climbing gear
 - Don't climb a crank-up tower supported only by its lift cable block and secure it first
 - -Use a gin pole to lift heavy items
 - -Don't work alone use a ground crew











Shorting the terminals can cause burns, fire, or an explosion













What is a good way to guard against electrical shock at your station?

Use three-wire cords and plugs for all AC powered equipment


Connect all AC powered station equipment to a common safety ground


Use a circuit protected by a ground-fault interrupter






Ground all of the protectors to a common plate which is in turn connected to an external ground









































So that if the antenna falls unexpectedly, no part of it can come closer than 10 feet to the power wires












Separate eight-foot long ground rods for each tower leg, bonded to the tower and each other




























What is the maximum power level that an amateur radio station may use at VHF frequencies before an RF exposure evaluation is required?


All power levels require an RF Exposure
Evaluation!


This is a change from what is stated in your


manuals!
















By calculation based on FCC OET Bulletin 65
By calculation based on computer modeling
By measurement of field strength using calibrated
equipment

















By re-evaluating the station whenever an item of equipment is changed














RF radiation does not have sufficient energy to cause genetic damage





